


AirMax DPB60 SERIES PAVING BREAKER

DPB601-1/4"
 DPB60(S)1-1/4"
 DPB601-1/8"
 DPB60(S)1-1/8"

PARTS ILLUSTRATION WITH PARTS LIST



01	52046	Cylinder	20	68073	Plug (oil regulator)	35a	43512	Pipe (air inlet swivel)
02	48385	Cylinder Plugs (3-5)	21	6646A	Fronthead (1-1/8)	35b	45259	Oring (swivel pipe)
03	43436	Piston	21	6649A	FH complete (1-1/8)	36	43169	Nut (swivel pipe)
04	43186	Valve (auto-cycling)	21	6646B	Fronthead (1-1/4)	37	91881	Oring (swivel nut)
05	43432	Valve Chest	21	6649B	FH complete (1-1/4)	38	43510	Screen (air inlet)
06	43431	Valve Seat	23	52049	Bolt (backhead)	39	43415	Bolt (fronthead)
07	43430	Valve Guide	24	43143	Washer (backhead)	40	43414	Nut (fronthead)
08	43477	Pin (valve chest)	25	43500	Nut (backhead)	41	91468	Washer (fronthead)
09	43474	Plunger (backhead)	26	43437	Tappet Seat	42	43412	Spring (fronthead)
10	43475	Spring (backhead)	27	43408	Tappet	43a	6644-A	Bushing (1-1/8)
11	52048	Backhead (bare)	28	43527	Latch	43b	6644-B	Bushing (1-1/4)
12	82907	Seal (TV port)	29	43524	Bolt (latch)	50	23450	Pin (safety lever)
13	43476	Grips (2)	30	43525	Nut (latch)	51	23451	Lever (safety)
14	46893	Throttle Valve	31	43007	Washer (latch)	52	23452	Spring (safety lever)
15	43395	Bushing (TV guide)	32	45605	Cone-Steel (latch)(2)			
16	43397	Spring (throttle valve)	32	43523	Cone-Rubber (latch)(2)			
17	43428	Lever (throttle valve)	33	43522	Plunger (latch)			
18	43393	Pin (throttle lever)(2)	34	43521	Spring (latch)			
19	43175	Plug (oil chamber)						

OPTIONS

98	17752	Muffler (complete)
99	10P75	Oiler (pressure feed)